

IMPORTANT NOTES

- IN APPLICATION WHERE THE UNIT IS CENTERED INSIDE A STAIRCASE, USE THE PIT RING DIMENSION OF THE UNIT AS THE MINIMUM DIMENSION INSIDE THE STAIRCASE
- THE UNIT CANNOT SERVE AS A FALL BARRIER, A HANDRAIL IS REQUIRED ON THE INTERIOR OF THE STAIRCASE.







DISCONNECTS AND CONTROLLER (REMOTE)

OFFICE USE ONLY:


CONFIGURATION VERSION STAMP: 1.5

MODULE VERSION STAMP: VUE_1.0.5

Part No. Round Mini Acrylic

Variant No.

SHEET No.



CUSTOMER