

VISIONS BY

*GENERAL_ HOISTWAY MUST BE IN ACCORDANCE WITH SAFETY CODE FOR ELEVATORS (ASME A17.1 OR B44-2000) AND ALL STATE/PROVINCIAL AND LOCAL CODES.

PLUMB HDISTWAY- DUE TO CLOSE RUNNING CLEARANCES OWNER/AGENT MUST ENSURE THAT HOISTWAY AND PIT (WHERE PROVIDED) ARE LEVEL, PLUMB AND SQUARE AND ARE IN ACCORDANCE WITH THE DIMENSIONS ON THESE DRAWINGS.

<u> (ERHEAD CLEARANCE</u> OWNER/AGENT MUST ENSURE MINIMUM CLEARANCE IS IN COMPLIANCE WITH CODES.

CONSTRUCTION SITE— OWNER/AGENT TO PROVIDE ALL MASONRY, CARPENTRY AND DRYWALL WORK AS REQUIRED AND SHALL PATCH AND MAKE GOOD (INCLUDING FINISH PAINTING) ALL AREAS WHERE WALLS/FLOORS MAY REQUIRE TO BE CUT, DRILLED OR ALTERED IN ANY WAY TO PERMIT THE PROPER INSTALLATION OF THE LIFT.

ELDOR/SUPPORT WALL LOADS- STRUCTURAL ENGINEER TO ASSURE THAT BUILDING AND SHAFT WILL SAFELY SUPPORT ALL LOADS IMPOSED BY THE LIFT EQUIPMENT. REFER TO THE TABLES ON THIS DRAWING FOR LOADS IMPOSED BY THE EQUIPMENT.

UITABLE LINTELS MUST BE PROVIDED BY OWNER/AGENT. MES ARE NOT DESIGNED TO SUPPORT OVERHEAD WALL

ACCESS- MACHINE ROOM LOCATED AT THE LOWEST JACENT TO HOISTWAY, UNLESS SHOWN OTHERWISE ON THE RAWINGS. FIELD ADJUSTMENT BY INSTALLER MAY BE Y TO MEET JOB SITE CONDITIONS OR REGULATIONS. ACCES A MEET JOB SITE CONDITIONS OR REGULATIONS. ACCESS

<u>SLEEVES FOR OIL & ELECTRIC LINES-</u> PROVIDED BY OTHERS, FROM MACHINE ROOM TO HOISTWAY. (POSITION PER INSTALLERS INSTRUCTIONS).

	15	15	115/1PH	B LIGHTS
21	40	60	230/1PH/60HTZ	
15.6	30	30	TOR INFO 208/3PH/60HTZ	TOR INFO
(V/PH/CYCLE) SIZE (AMPS) FUSE (AMPS) CURRENT (AMPS)	FUSE (AMPS)	SIZE (AMPS)	(V/PH/CYCLE)	
FULL LOAD	TIME DELAY	DISCONNECT	INPUT VOLTAGE DISCONNECT TIME DELAY FULL LOAD	

POWER SUPPLY— (SEE SPECIFICATIONS) LOCKABLE FUSED DISCONNECT WITH AUXILIARY CONTACT TO BRAKE THE BATTERY FEED, OR CIRCUIT BREAKERS WITH A 3-POLE BREAKER FOR BATTERY FEED REQUIRED, IN COMPLIANCE WITH ELECTRICAL CODE, AS FOLLOWS:

POWER- BEFORE INSTALLATION CAN BEGIN, PERMANENT

<u>LIGHTING-</u> DWNER/AGENT TO ENSURE AT LEAST 5 FTC OR 54 LUX AMBIENT LIGHTING OVER ELEVATOR AREA.

*ENTRANCES

FASCIA PANEL BELOW UPPER LEVEL ENTRANCE- WHERE RE
FASCIA PANEL MUST BE FASTENED TO A SOLID WALL AND
PERPENDICULAR TO THE FLOOR AND WALLS. HOISTWAY
FASCIA IS NOT SELF-SUPPORTING FOR LONG, CONTINUOUS
RUNS VOID OF ENTRANCES. ADEQUATE SUPPORT AND THE
FASCIA MUST BE PROVIDED BY OTHERS. ASSEMBLIES- ENTRANCE ASSEMBLIES MUST BE ADJUSTED WITH PLATFORM AND INTERLOCK EQUIPMENT. OTHERS TO ADEQUATE ROUGH OPENING. REQUIRED,

REV-000

MODEL LU/ 4260

1R)